



The S.A.F.E. is typically installed between gaskets and raised face flanges -- rtj flange installation is also available by special order. The recommended installation location will differ depending on the surrounding installation. Please contact Savant Measurement for assistance in determining the best location for your application.

Savant M EASUREMENT		C ORPORATION	
TITLE: S.A.F.E.			
B	DWG. NO. SAFE Install		REV. A
DATE 3/30/05	SCALE n/a	SHEET 1 of 1	